

FX100

AUDIO ANALYZER



PACKAGE LIST

- FX100 Audio Analyzer
- Mains cable
- USB cable
- FLEXUS USB Memory Stick (PC software and product information)
- Calibration certificate
- This quick guide



OPERATING CONDITIONS & SAFETY ADVICE

- Required mains power: 90 - 264 VAC / 47 - 63Hz.
- Maximum voltage at analog inputs: 200Vp.
- Do not apply AC voltages to analog outputs.
- Environmental conditions
- Operating: 5°C to 45°C / 90% RH non-condensing.
- Storage: -20°C to 80°C / 90% RH non-condensing.
- You may stack up to four FLEXUS units.
- Keep front panel ventilation inlet holes open.
- For detailed specifications see www.nti-audio.com/flexus





MAINTENANCE

- There are no serviceable parts inside.
- Clean surface with a dry cleaning cloth.
You may use a mild cleaning agent if required.




INTRODUCTION

Make yourself familiar with the connections, controls and elements of your FX100 Audio Analyzer.





START OF OPERATION

1. Unpack items.
2. Install software.
 - Insert FLEXUS USB Memory Stick into your PC.
 - Open drive folder and double-click on setup.exe.
 - Follow installation instructions.
3. Connect FLEXUS to mains power.
4. Connect FLEXUS and PC with USB cable, using the USB-B connector.
5. Launch FX-Control. 
6. FX-Control will start with a default measurement project
7. For further information on how to operate FX-Control, please use the online help via the “F1” key.



HOW TO ...


OPERATE THE FX 100 FRONT PANEL



The FX100 can be operated with the Push&Turn wheel on the front panel. It allows navigating through a menu system.

- By turning the wheel, the highlighted active item can be changed.
- By pressing on a active item, the functionality gets active.

PERFORM A FIRMWARE UPGRADE




If there is a new firmware available, FX-Control will notify you upon startup.

- Confirm and download the *fxu file to the root folder of an USB memory stick.
- Plug the USB memory stick into one of the USB Type-A connectors of your FLEXUS unit.
- Select the FLEXUS menu **SYSTEM** > **=VER** > **FW-UPDATE**

- Select the stored fxu file from the list.
- The firmware upgrade will proceed automatically. This may take up to a few minutes. Do not switch off the unit during the firmware upgrade process.

SET THE FLEXUS DATE AND TIME



- Select the FLEXUS menu **SYSTEM > =TIME**
- Set the correct date and time

CONFIGURE THE HEADPHONE OUTPUT



Content

- MONITOR (the unfiltered analyzer input signal).
- PURESOUND (the bandlimited PureSound analysis input filter).

Source

- The analyzer channel number routed to the headphone output.

Volume

- Controls the volume from 0 % to 100 %.

PERFORM A SYSTEM CHECK

- Navigate through the FLEXUS menus to **SYSTEM > =TST**
- The system will perform a few basic tests and return **PASSED** or **FAILED**

DETERMINE THE CALIBRATION DUE DATE

- Navigate through the FLEXUS menus to **SYSTEM > ?CAL**
- The system will display the last calibration date, and the next validation due date.

GET FURTHER INFORMATION AND SUPPORT

- Register your FX100 under <http://my.nti-audio.com> for product news, firmware and software updates.
- Consult the FX100 user manual on the FLEXUS USB Memory Stick.
- Contact your local NTi Audio partner for technical support.