

	Basic Loudspeaker Test Software	Standard Loudspeaker Test Software	Premiere Loudspeaker Test Software
Measurement Functions			
Automated calibration sequence	•	•	•
Reference measurements	•	•	•
PureSound Rub&Buzz defect detection	•	•	•
Frequency response		•	•
Impedance response		•	•
Distortion response		•	•
Thiele/Small parameters		•	•
Multiple Resonance frequency readings		•	•
Multiple dB SPL readings		•	•
Multiple Polarity readings		•	•
DC Resistance		•	•
2-DUT parallel measurement			•
Loudspeaker directivity (Polar plots)			•
Interface			
Front panel PASS/FAIL indication	•	•	•
Temperature & Humidity sensor support	•	•	•
Barcode scanner support		•	•
Digital IO interface			•
DUT auto detect			•
TPC/IP remote control			•
Remote monitoring			•
Audio switcher support			•
Pre/Post-test actions			•
Turntable support			•
Data Handling			
Data Logging	•	•	•
Golden Sample finder (BMA)		•	•
Serial number handling		•	•
Result classifying			•
Statistic package			•
Administratives			
Calibration manager	•	•	•
Project Backup/Restore	•	•	•
Project sequencing		•	•
User role management			•
Multiple cycles			•
Automated documentation			•
Customized reports			•