

For further media information please contact  
Isabella Niffeler, PR Manager  
i.niffeler@nti-audio.com  
+423 239 60 60

September 2009

## NTi Audio reveals the new flagship: XL2 Audio and Acoustic Analyzer

**NTi Audio AG presents its new handheld flagship: the XL2 Audio and Acoustic Analyzer. The XL2 analyzer forms the unique combination of a state-of-the-art sound level meter, a comprehensive acoustical analyzer as well as a powerful audio analyzer. The wide range of functionalities is tailored for Live Sound, Installed Sound, Studios, Service and Environmental Noise measurements.**

The XL2 provides together with the measurement microphones M4260 (Class 2) or M2210 (Class 1 frequency response) a precise sound level meter for monitoring of live sound events and environmental noise. The instrument generates the 48V phantom power supply for the microphones and reads the included electronic data sheet of the M4260 and M2210 automatically. This promotes faster setup and ensures accurate measurements. Additionally the XL2 logs the calibration data and microphone serial number at each measurement.

### **Measurement Results stored to 2 GB Mini-SD card**

The four fast access buttons together with the rotary wheel enable an intuitive instrument operation for precise measurements. The recorded measurement data can be transferred to PC either by the USB interface or directly from the Mini-SD card for later documentation.

### **Flexible User Interface**

A remarkable advantage of the XL2 is the flexible user interface. The measurement screens may be personalized and only a limited subset of the comprehensive functionalities enabled for simplified operator interfaces. Advanced users may access all menus, settings and store their preferred measurement configurations. For basic users offers the XL2 Audio and Acoustic Analyzer fixed operator interfaces with specific pre-defined settings. The XL2 boots up with exactly the required measurement parameters according the pre-defined instrument configurations. This ensures precise measurement results achieved by advanced and basic users.

NTi Audio AG  
info@nti-audio.com  
+423 239 6060

NTI Americas Inc.  
americas@nti-audio.com  
+1 503 684 7050

NTI Japan  
japan@nti-audio.com  
+81 3 3634 6110

NTI China  
china@nti-audio.com  
+86 512 6802 0075

[www.nti-audio.com](http://www.nti-audio.com)

The XL2 Audio and Acoustic Analyzer is available now.

Read more at: [www.nti-audio.com/XL2](http://www.nti-audio.com/XL2)

---

### **About NTi Audio**

NTi Audio AG develops highly qualified and customized measurement solutions for the pro audio and telecommunications industry. NTi Audio's main product lines are the handheld EXEL line, the A-Series audio analyzers, the RAPID-TEST production line test systems as well as complete turnkey tests solutions based on PureSound – a unique defects analysis technology. The headquarters of NTi Audio are in the Principality of Liechtenstein (Europe). Subsidiaries are NTI Americas Inc in Portland, NTI China in Suzhou and NTI Japan in Tokyo. NTi Audio AG is the new company name of the earlier NTI AG.

### **Information for journalists:**

Hi-res product pictures are available at the NTi Audio website - press area:  
[www.nti-audio.com/tabid/220/Default.aspx](http://www.nti-audio.com/tabid/220/Default.aspx)