



Charge indication check

Use of the battery

Connect the DC output of the battery pack with the DC input of the TalkBox using the provided connection cable and the G/G4 adaptor. As soon as the connection is established, the NTi Audio TalkBox starts running. For storage or when not used for a longer period of time, please disconnect the battery cable preventing the complete discharging of the battery. To check the charge indication, press the black charge test button and the three green LED will indicate the charge level.

Technical data

- Battery type: Li-Ion Battery
- Input voltage: 12 V - 24 VDC, 1 A max.
- Output voltage: 9V, 2A max.
- Capacity: 48 Watt hours nominal
- Dimensions: 153 mm x 93 mm x 23mm
(6" x 3.72" x 0.9")
- Weight: 400g (0.8 lbs)

Running time with battery pack (typical)

- Idle mode: Standby, electrical output: 15 hours
- STI-PA: Output on (60dB_{SPL}) 12 hours
- STI-PA Lombard: Output on (70dB_{SPL}) 7 hours

All information subject to change without notice.
NTi Audio TalkBox is a Trademark of NTi Audio AG.

NTi Audio AG
Im alten Riet 102
9494 Schaan
Liechtenstein, Europe
Phone +423 239 60 60
Fax +423 239 60 89
info@nti-audio.com

NTi Americas Inc.
PO Box 231027
Tigard, Oregon 97281
USA
Phone +1 503 684 7050
Fax +1 503 684 7051
americas@nti-audio.com

NTi China Ltd.
Room 722, 7F, Building 6-3A,
No 1388, Bin He Rd.
215000 Suzhou, China
Phone +86 512 6802 0075
Fax +86 512 6802 0097
china@nti-audio.com

NTi Japan Ltd.
Ryogokusakamoto Bldg. 1-8-4
Ryogoku, 130-0026 Sumida-ku
Tokyo, Japan
Phone +81 3 3634 6110
Fax +81 3 3634 6160
japan@nti-audio.com